

NASA TECHNICAL  
MEMORANDUM

NASA TM X-53286

June 24, 1965

NASA TM X-53286

GPO PRICE \$ \_\_\_\_\_

CFSTI PRICE(S) \$ \_\_\_\_\_

Hard copy (HC) 5.00

Microfiche (MF) 1.00

ff 653 July 65

VACUUM COMPATIBILITY OF ENGINEERING  
MATERIALS (SOLIDS) II

by J. G. AUSTIN AND J. B. GAYLE  
Propulsion and Vehicle Engineering Laboratory

NASA

*George C. Marshall  
Space Flight Center,  
Huntsville, Alabama*

FACILITY FORM 802

N65-29647

(ACCESSION NUMBER)

166  
(PAGES)

TM X-53286  
(NASA CR OR TMX OR AD NUMBER)

(THRU)

1  
(CODE)

06  
(CATEGORY)

TECHNICAL MEMORANDUM X-53286

VACUUM COMPATIBILITY OF ENGINEERING  
MATERIALS (SOLIDS) II

By J. G. Austin and J. B. Gayle

George C. Marshall Space Flight Center  
Huntsville, Alabama

ABSTRACT

29647

The rate and extent of weight loss of 62 solid materials in a vacuum environment were determined experimentally by continuous and intermittent weighing techniques. Test conditions ranged from 41°C to 200°C at pressures of  $10^{-2}$  to  $10^{-5}$  torr. The results are presented in 2 tables and 130 figures.

*Author*

NASA - GEORGE C. MARSHALL SPACE FLIGHT CENTER

NASA - GEORGE C. MARSHALL SPACE FLIGHT CENTER

\_\_\_\_\_ 217 20017  
TECHNICAL MEMORANDUM X-53286  
\_\_\_\_\_

VACUUM COMPATIBILITY OF ENGINEERING  
MATERIALS (SOLIDS) II

By J. G. Austin and J. B. Gayle

CHEMISTRY BRANCH  
MATERIALS DIVISION  
PROPULSION AND VEHICLE ENGINEERING LABORATORY  
RESEARCH AND DEVELOPMENT OPERATIONS

## TABLE OF CONTENTS

	Page
SUMMARY.....	1
INTRODUCTION.....	1
EXPERIMENTAL.....	2
Short-Term Exposure with Continuous Weighing.....	2
Extended Exposure with Intermittent Weighing.....	3
DISCUSSION OF RESULTS.....	3
REFERENCES.....	6

## LIST OF TABLES

Table	Title	Page
I	Continuous Weighing Test.....	7
II	Intermittent Weighing Test.....	15

## LIST OF ILLUSTRATIONS

Figure	Title	Page
1	Continuous Recording Automatic Electrobalance.....	23
2	Ceramic Oven for Heating Test Specimens in Vacuum.....	24
3	Time-Weight Histories for DC 7170 During Exposure to Vacuum at 49°C and 50°C.....	25
4	Time-Weight Histories for DC 7170 During Exposure to Vacuum at 98°C and 100°C.....	26
5	Time-Weight Histories for Marlex 6002 During Exposure to Vacuum at 50°C and 53°C.....	27
6	Time-Weight Histories for Marlex 6002 During Exposure to Vacuum at 100°C.....	28
7	Time-Weight Histories for Geon 2046 During Exposure to Vacuum at 43°C, 50°C, and 52°C.....	29
8	Time-Weight Histories for Geon 2046 During Exposure to Vacuum at 99°C and 100°C.....	30
9	Time-Weight Histories for Geon 8800 During Exposure to Vacuum at 50°C.....	31
10	Time-Weight Histories for Geon 8800 During Exposure to Vacuum at 99°C and 100°C.....	32
11	Time-Weight Histories for Estane 5740 During Exposure to Vacuum at 50°C and 73°C.....	33
12	Time-Weight Histories for Estane 5740 During Exposure to Vacuum at 97°C and 100°C.....	34

# LIST OF ILLUSTRATIONS (Continued)

Figure	Title	Page
13	Time-Weight Histories for Royaline-R During Exposure to Vacuum at 49°C, 50°C, and 52°C.....	35
14	Time-Weight Histories for Royaline-R During Exposure to Vacuum at 99°C and 100°C.....	36
15	Time-Weight Histories for Kel-F 81 During Exposure to Vacuum at 48°C and 50°C.....	37
16	Time-Weight Histories for Kel-F 81 During Exposure to Vacuum at 100°C.....	38
17	Time-Weight Histories for Tedlar During Exposure to Vacuum at 50°C and 51°C.....	39
18	Time-Weight Histories for Tedlar During Exposure to Vacuum at 87°C, 99°C, and 100°C.....	40
19	Time-Weight Histories for Teflon FEP During Exposure to Vacuum at 47°C and 50°C.....	41
20	Time-Weight Histories for Teflon FEP During Exposure to Vacuum at 100°C and 101°C.....	42
21	Time-Weight Histories for Duroid 5600 During Exposure to Vacuum at 48°C and 50°C.....	43
22	Time-Weight Histories for Duroid 5600 During Exposure to Vacuum at 100°C and 101°C.....	44
23	Time-Weight Histories for Acrylic Coat During Exposure to Vacuum at 50°C.....	45
24	Time-Weight Histories for Acrylic Coat During Exposure to Vacuum at 100°C and 101°C.....	46
25	Time-Weight Histories for Silicone Thermal Coating During Exposure to Vacuum at 50°C.....	47
26	Time-Weight Histories for Silicone Thermal Coating During Exposure to Vacuum at 100°C.....	48
27	Time-Weight Histories for RTV-60 During Exposure to Vacuum at 47°C and 50°C.....	49

# LIST OF ILLUSTRATIONS (Continued)

Figure	Title	Page
28	Time-Weight Histories for RTV-60 During Exposure to Vacuum at 100°C, 102°C, and 120°C.....	50
29	Time-Weight Histories for RTV-501 During Exposure to Vacuum at 50°C and 51°C.....	51
30	Time-Weight Histories for RTV-601 During Exposure to Vacuum at 50°C and 54°C.....	52
31	Time-Weight Histories for RTV-601 During Exposure to Vacuum at 94°C, 100°C, 105°C, 106°C, and 119°C..	53
32	Time-Weight Histories for DCR-7521 During Exposure to Vacuum at 53°C.....	54
33	Time-Weight Histories for DCR-7521 During Exposure to Vacuum at 100°C and 114°C.....	55
34	Time-Weight Histories for EC 2273 During Exposure to Vacuum at 49°C, 50°C, 52°C, and 54°C.....	56
35	Time-Weight Histories for EC 2273 During Exposure to Vacuum at 98°C and 104°C.....	57
36	Time-Weight Histories for Durock D-133 During Exposure to Vacuum at 50°C and 57°C.....	58
37	Time-Weight Histories for Durock D-133 During Exposure to Vacuum at 100°C and 114°C.....	59
38	Time-Weight Histories for FM-47 During Exposure to Vacuum at 50°C, 51°C, and 55°C.....	60
39	Time-Weight Histories for FM-47 During Exposure to Vacuum at 100°C.....	61
40	Time-Weight Histories for Paraplex P-43 During Exposure to Vacuum at 50°C and 58°C.....	62
41	Time-Weight Histories for Paraplex P-43 During Exposure to Vacuum at 99°C and 105°C.....	63
42	Time-Weight Histories for CTL-91-LD During Exposure to Vacuum at 50°C and 54°C.....	64

# LIST OF ILLUSTRATIONS (Continued)

Figure	Title	Page
43	Time-Weight Histories for CTL-91-LD During Exposure to Vacuum at 100°C, 104°C, and 105°C.....	65
44	Time-Weight Histories for Epon 828 During Exposure to Vacuum at 48°C, 50°C, and 55°C.....	66
45	Time-Weight Histories for Epon 828 During Exposure to Vacuum at 100°C and 101°C.....	67
46	Time-Weight Histories for DC-2104 During Exposure to Vacuum at 50°C.....	68
47	Time-Weight Histories for DC-2104 During Exposure to Vacuum at 100°C.....	69
48	Time-Weight Histories for DC-2106 During Exposure to Vacuum at 41°C, 47°C, and 50°C.....	70
49	Time-Weight Histories for DC-2106 During Exposure to Vacuum at 100°C, 103°C, 105°C, and 150°C.....	71
50	Time-Weight Histories for HRP Honeycomb During Exposure to Vacuum at 50°C and 51°C.....	72
51	Time-Weight Histories for HRP Honeycomb During Exposure to Vacuum at 100°C and 103°C.....	73
52	Time-Weight Histories for Viton B During Exposure to Vacuum at 48°C and 50°C.....	74
53	Time-Weight Histories for Viton B During Exposure to Vacuum at 100°C, 149°C, and 198°C.....	75
54	Time-Weight Histories for PRP 73770 During Exposure to Vacuum at 47°C and 50°C.....	76
55	Time-Weight Histories for PRP 73770 During Exposure to Vacuum at 99°C, 100°C, and 101°C.....	77
56	Time-Weight Histories for PRP 8187 During Exposure to Vacuum at 46°C and 50°C.....	78
57	Time-Weight Histories for PRP 8187 During Exposure to Vacuum at 100°C and 101°C.....	79



# LIST OF ILLUSTRATIONS (Continued)

Figure	Title	Page
58	Time-Weight Histories for Urethane DS-620 During Exposure to Vacuum at 50°C and 56°C.....	80
59	Time-Weight Histories for Urethane DS-620 During Exposure to Vacuum at 100°C.....	81
60	Time-Weight Histories for Eccofoam Q During Exposure to Vacuum at 50°C and 51°C.....	82
61	Time-Weight Histories for Eccofoam Q During Exposure to Vacuum at 99°C and 100°C.....	83
62	Time-Weight Histories for Refrasil B-100 During Exposure to Vacuum at 50°C and 51°C.....	84
63	Time-Weight Histories for Refrasil B-100 During Exposure to Vacuum at 100°C and 101°C.....	85
64	Time-Weight Histories for CPR-20 During Exposure to Vacuum at 43°C, 48°C, and 50°C.....	86
65	Time-Weight Histories for CPR-20 During Exposure to Vacuum at 100°C.....	87
66	Time-Weight Histories for CPR-1021 During Exposure to Vacuum at 50°C and 54°C.....	88
67	Time-Weight Histories for CPR-1021 During Exposure to Vacuum at 99°C and 100°C.....	89
68	Time-Weight Histories for Duroid 5813 During Exposure to Vacuum at 50°C.....	90
69	Time-Weight Histories for Duroid 5813 During Exposure to Vacuum at 100°C and 101°C.....	91
70	Time-Weight Histories for Epon VIII During Exposure to Vacuum at 50°C and 51°C.....	92
71	Time-Weight Histories for Epon VIII During Exposure to Vacuum at 100°C.....	93
72	Time-Weight Histories for APCO 1252 During Exposure to Vacuum at 50°C, 52°C, and 54°C.....	94

# LIST OF ILLUSTRATIONS (Continued)

Figure	Title	Page
73	Time-Weight Histories for APCO 1252 During Exposure to Vacuum at 100°C.....	95
74	Time-Weight Histories for Shell 929 During Exposure to Vacuum at 50°C and 52°C.....	96
75	Time-Weight Histories for Shell 929 During Exposure to Vacuum at 100°C and 105°C.....	97
76	Time-Weight Histories for Shell 934 During Exposure to Vacuum at 43°C and 50°C.....	98
77	Time-Weight Histories for Shell 934 During Exposure to Vacuum at 78°C and 100°C.....	99
78	Time-Weight Histories for HT-424 During Exposure to Vacuum at 50°C.....	100
79	Time-Weight Histories for HT-424 During Exposure to Vacuum at 100°C.....	101
80	Time-Weight Histories for Narmco A During Exposure to Vacuum at 50°C.....	102
81	Time-Weight Histories for Narmco A During Exposure to Vacuum at 100°C.....	103
82	Time-Weight Histories for Narmco C During Exposure to Vacuum at 50°C, 54°C, and 57°C.....	104
83	Time-Weight Histories for Narmco C During Exposure to Vacuum at 100°C.....	105
84	Time-Weight Histories for Aerobond 430 During Exposure to Vacuum at 50°C and 57°C.....	106
85	Time-Weight Histories for Aerobond 430 During Exposure to Vacuum at 100°C.....	107
86	Time-Weight Histories for FM-1000 During Exposure to Vacuum at 50°C.....	108
87	Time-Weight Histories for FM-1000 During Exposure to Vacuum at 100°C and 101°C.....	109

# LIST OF ILLUSTRATIONS (Continued)

Figure	Title	Page
88	Time-Weight Histories for Narmco 302A During Exposure to Vacuum at 50°C.....	110
89	Time-Weight Histories for Narmco 302A During Exposure to Vacuum at 100°C.....	111
90	Time-Weight Histories for AF-6 During Exposure to Vacuum at 50°C.....	112
91	Time-Weight Histories for AF-6 During Exposure to Vacuum at 100°C.....	113
92	Time-Weight Histories for AF-40 During Exposure to Vacuum at 48°C and 50°C.....	114
93	Time-Weight Histories for AF-40 During Exposure to Vacuum at 100°C and 102°C.....	115
94	Time-Weight Histories for Narmco 4021 During Exposure to Vacuum at 49°C and 50°C.....	116
95	Time-Weight Histories for Narmco 4021 During Exposure to Vacuum at 100°C.....	117
96	Time-Weight Histories for Narmco 408 During Exposure to Vacuum at 50°C.....	118
97	Time-Weight Histories for Narmco 408 During Exposure to Vacuum at 99°C and 100°C.....	119
98	Time-Weight Histories for Selectron 5003 During Exposure to Vacuum at 50°C.....	120
99	Time-Weight Histories for Selectron 5003 During Exposure to Vacuum at 95°C and 100°C.....	121
100	Time-Weight Histories for Kynar During Exposure to Vacuum at 50°C.....	122
101	Time-Weight Histories for Kynar During Exposure to Vacuum at 100°C.....	123

# LIST OF ILLUSTRATIONS (Continued)

Figure	Title	Page
102	Time-Weight Histories for MB 302A During Exposure to Vacuum at 50°C.....	124
103	Time-Weight Histories for MB 302A During Exposure to Vacuum at 100°C.....	125
104	Time-Weight Histories for MB 406 During Exposure to Vacuum at 50°C and 54°C.....	126
105	Time-Weight Histories for MB 406 During Exposure to Vacuum at 100°C.....	127
106	Time-Weight Histories for MB 4021 During Exposure to Vacuum at 50°C.....	128
107	Time-Weight Histories for MB 4021 During Exposure to Vacuum at 100°C and 102°C.....	129
108	Time-Weight Histories for Scotchcast 212 During Exposure to Vacuum at 50°C.....	130
109	Time-Weight Histories for Scotchcast 212 During Exposure to Vacuum at 100°C and 103°C.....	131
110	Time-Weight Histories for EC 1949 During Exposure to Vacuum at 50°C.....	132
111	Time-Weight Histories for EC 1949 During Exposure to Vacuum at 98°C and 100°C.....	133
112	Time-Weight Histories for EC 1663 During Exposure to Vacuum at 50°C and 51°C.....	134
113	Time-Weight Histories for EC 1663 During Exposure to Vacuum at 100°C.....	135
114	Time-Weight Histories for PR-1538 During Exposure to Vacuum at 50°C.....	136
115	Time-Weight Histories for PR-1538 During Exposure to Vacuum at 100°C and 101°C.....	137
116	Time-Weight Histories for Molykote X-15 During Exposure to Vacuum at 50°C.....	138

# LIST OF ILLUSTRATIONS (Concluded)

Figure	Title	Page
117	Time-Weight Histories for Molykote X-15 During Exposure to Vacuum at 100°C.....	139
118	Time-Weight Histories for Electrofilm 66-C During Exposure to Vacuum at 44°C, 49°C, and 50°C..	140
119	Time-Weight Histories for Electrofilm 66-C During Exposure to Vacuum at 100°C.....	141
120	Time-Weight Histories for MLF-5 During Exposure to Vacuum at 50°C.....	142
121	Time-Weight Histories for MLF-5 During Exposure to Vacuum at 100°C.....	143
122	Time-Weight Histories for ETR-H During Exposure to Vacuum at 50°C and 54°C.....	144
123	Time-Weight Histories for ETR-H During Exposure to Vacuum at 100°C.....	145
124	Time-Weight Histories for Epoxy Coating on Aluminum During Exposure to Vacuum at 49°C and 50°C.....	146
125	Time-Weight Histories for Epoxy Coating on Aluminum During Exposure to Vacuum at 98°C and 100°C.....	147
126	Time-Weight Histories for Epoxy Coating Peeled Off Glass During Exposure to Vacuum at 47°C and 50°C.....	148
127	Time-Weight Histories for Epoxy Coating Peeled Off Glass During Exposure to Vacuum at 100°C and 103°C.....	149
128	Time-Weight Histories for Merlon During Exposure to Vacuum at 54°C and 55°C.....	150
129	Time-Weight Histories for Merlon During Exposure to Vacuum at 137°C and 140°C .....	151
130	Comparison of Results from Continuous Weighing Test and Intermittent Weighing Test.....	152

# VACUUM COMPATIBILITY OF ENGINEERING MATERIALS (SOLIDS) II

By J. G. Austin and J. B. Gayle  
George C. Marshall Space Flight Center

## SUMMARY

29647

The rate and extent of weight loss of 62 solid materials in a vacuum environment were determined by continuous and before-and-after weighings. The effects of temperature on weight loss were determined by testing the materials at temperatures ranging from 41°C to 200°C; however, most tests were made at either 50°C or 100°C. The weight loss varied from nil (limit of detection, 0.3 mg) to 23 percent. All continuous weighing tests were limited to 24 hours, and all intermittent tests were limited to 31 days of vacuum exposure. A comparison was made of results for the continuous and intermittent weighing techniques for an exposure of 24 hours; the agreement generally was good.

*author*

## INTRODUCTION

Vacuum compatibility is a major factor influencing the selection of materials for space vehicle applications. Many materials lose weight when exposed to a vacuum environment. The rate and extent of this loss depend on a number of factors, including the temperature, pressure, and chemical composition of the material. A knowledge of the rate and extent of material loss in a vacuum environment can be used for preliminary screening, thereby reducing the number of materials to be subjected to altitude simulation tests in hardware configuration.

A program for testing the compatibility of materials in vacuum was initiated by the Engineering Materials Branch in 1959 (presently the Materials Division). The equipment and test procedures used for these investigations and the results obtained for a number of materials have been discussed in previous reports (ref. 1, 2, 3, 4, and 5). This report presents additional results for a number of solid materials. Results for many materials, particularly those exhibiting small weight losses, depend on their physical state, the presence of trace impurities, and/or minor changes in composition. Therefore, results have been included for several materials that were at least superficially similar to materials that had been tested before. In some instances, the new materials were made by different manufacturers.

## EXPERIMENTAL

### Short-Term Exposure with Continuous Weighing

Four vacuum systems, designated 4A, 4B, 4D, and 4E, were used. All systems were equipped with 4-inch diffusion pumps and differed primarily in the degree of automatic operation. The 4A and 4D systems had manually operated pumping equipment. The 4E system was fitted with manually operated vacuum valves; however, the valve arrangement allowed the continuous operation of the fore and diffusion pumps when the bell jar was vented to the atmosphere. All four vacuum systems were equipped with automatic electrobalances (FIG 1) and ceramic ovens (FIG 2) for elevated-temperature experimentations.

An effort was made to standardize the test specimens to approximately one centimeter square; however, such factors as balance weight limitations, available material configurations, and sample density resulted in the variations in size and shape as noted in the tables. All specimens were desiccated for 24 hours before being weighed and placed in the vacuum chambers.

The balances used were of two types: (1) ordinary analytical balances for before-and-after weighing; (2) Cahn electrobalances for weighing in vacuum. In all of the systems, continuous records of weights were provided by a strip chart recording of the automatic balance outputs. The zero settings and calibration factors of the balances were determined before each test. Thermal effects on the automatic balances were considered to be small since thermocouples at various locations within the bell jar indicated that heating was confined largely to the ceramic ovens.

After a weighed specimen was placed in the vacuum chamber, a pressure below  $10^{-4}$  torr was achieved in less than 10 minutes; then the specimens were heated to the preselected test temperature within 15 to 30 minutes. Ultimate pressure in all cases was less than  $10^{-5}$  torr. Most of the specimens were tested at 50°C and 100°C; the exceptions to those temperatures are noted in the tables.

In most cases, the continuous weight loss determinations for the specimens were terminated after 24 hours. After the specimens cooled to room temperature, they were removed from vacuum and weighed on the analytical balance. A more detailed description of this procedure has been presented in a previous report (ref. 1). Experience has indicated that variations due to weighing errors and other causes normally do not exceed 0.3 mg based on sample weights used in this investigation. The corresponding percentage errors ranged from 3.6 to 0.01; therefore, changes less than these values were not considered significant.

## Extended Exposure with Intermittent Weighing

The continuous weighing systems made it necessary for each specimen to be tested alone, so the testing period could not be extended beyond 24 hours without severely restricting the amount of data that could be acquired with the limited number of balances and vacuum systems available. To alleviate this situation, intermittent weighing tests were used to obtain data for vacuum exposures greater than 24 hours.

Groups of specimens of approximately 10 materials were spaced on a support screen and placed in one cubic foot vacuum ovens. Each oven was fitted with a mechanical fore pump and a two-inch oil diffusion pump, thus achieving an ultimate pressure of less than  $10^{-3}$  torr. The test temperature was maintained by a conventional oven temperature control system. No precaution was taken to preclude cross-contamination of the individual specimen by gaseous constituents evolved from other specimens. The specimens were weighed on an analytical balance before being placed in the vacuum oven; then, they were exposed for 24 hours, cooled to room temperature in vacuo, removed to a desiccator, weighed, and returned to the vacuum oven for an additional exposure period. This test sequence was repeated for 5 days and then once a week, for a total test time of 31 days.

At the conclusion of the vacuum exposure period, the samples were allowed to stand in air for 24 hours and weighed, then desiccated for 24 hours and reweighed. Any gain in weight resulting from air exposure was attributed to that portion of the total weight loss associated with moisture or other atmospheric constituents rather than a loss of the material itself.

## DISCUSSION OF RESULTS

Weight loss determinations were made on 62 materials that were obtained from commercial manufacturers. Specimens varied in surface area, thickness, and weight as dictated by balance limitations and available sample configurations. Tests were made at one or two temperatures, ranging from 41°C to 198°C; however, most samples were tested at 50°C and 100°C. The results are summarized in Table I for continuous weighing and in Table II for intermittent weighing. Figures 3 through 129 illustrate the rate and extent of weight loss for each material.

It should be noted that each weight loss history is a composite graphic representation of the results from both continuous and intermittent weighing tests for each material. Continuous weighing results, limited to 24 hours, are presented as a function of linear time. The extended exposure results that were obtained by the intermittent weighing



test are presented as a function of log time. The combined log-linear time scale is not intended to be indicative of the mechanism of evaporation but is only a device to more clearly present the results.

The apparent nonlinearity of the percent weight remaining versus time curves that were obtained by the continuous weighing procedure and also the extended exposure tests indicates a complex physical and chemical mechanism for weight loss. As expected, both rate and extent of weight loss increased with an increase in test temperature for most materials tested. However, in some materials, e.g., Dow Corning DC 7170 (FIG 3 and 4), there were no discernible differences in weight loss for the 50°C and the 100°C tests. Other materials, e.g., Geon 2046 (FIG 7 and 8) and PRP 73770 (FIG 54 and 55), showed moderate weight losses at 50°C with large increases in rate and extent of weight losses at 100°C. Such results suggest threshold temperatures corresponding to decomposition and/or evaporation of individual components of the various materials. For many of the continuous weighing tests, a slight but apparent weight loss followed by a regain in weight was registered during the first two to three hours of testing. Further examination of the experimental procedure and resultant data showed that this phenomenon began immediately after the specimen heating furnace had been turned on, which indicated a thermal effect. Experimental verification, using steel weights, indicated that an apparent weight loss of 0.5 mg was registered within the first two hours; then the indicated weight returned to the correct value. These data suggested that the deviation was caused by a temperature gradient within the balance system which resulted from some slight furnace heating; however, as thermal equilibrium was approached, the apparent weight loss diminished, and the proper value was recorded.

Preliminary examination of the results showed a good correlation between the rate and extent of weight loss obtained from continuous weighing and intermittent weighing techniques. In most cases, the latter test produced a relatively smooth extension of the continuous weighing weight loss curve. However, in a few cases, several days were required before the intermittent weighing test curves coincided with the extrapolated continuous weight loss curves, e.g., PRP 8187 (FIG 57.) This suggested an induction period for some materials in the intermittent weighing tests. In the continuous tests, bell jar pressures were reduced to  $10^{-5}$  torr within 10 minutes and to ultimate pressures less than  $10^{-5}$  torr within one hour. The intermittent test ovens exhibited much slower pumping speeds than the bell jar systems. During the first 5 days of testing, each oven was opened once every 24 hours, and the maximum rate of outgassing occurred. Pressures of  $10^{-2}$  torr were attained in 4 to 6 hours, and pressures less than  $10^{-3}$  torr were reached only after a 24-hour pumpdown time. It should be noted that the deviations between continuous and intermittent test results were

generally confined to the first three days of intermittent weighing test time, e.g., PRP 8187 (FIG 57). After this time, good agreement between the two test methods was obtained.

A possible source of error in the intermittent test results arises from the simultaneous testing of numerous samples of different materials in a single oven. However, for the same widely accepted reasons that material evaporating from a given sample is not expected to return to that sample when the pressure is low, material evaporating from any given sample would not be expected to contaminate other samples appreciably.

A previous report (ref. 2) showed that some materials regained weight on standing in air after vacuum exposure. This was considered to be caused by absorption of moisture and/or atmospheric gases. It was suggested that weight regain characteristics would be valuable in discerning between actual material loss and simple outgassing of the sample. To obtain this information, the intermittent weighing test specimens were allowed to stand in air for 24 hours and weighed, then desiccated for 24 hours and reweighed. The reweighings are represented on the weight loss histories by open triangles and closed triangles. Most of the materials that were tested reflected little change in this final treatment; however, some slight weight regains were exhibited, as shown by FM-1000 adhesive (FIG 86 and 87).

The agreement of the results of continuous weighing and intermittent weighing test methods for a 24-hour exposure was quite good, as shown in FIG 130. Inspection of the plotted data indicates that they are compatible with a straight line with intercept equal to zero and slope equal to unity or to conform to the equation,

$$y = x$$

where:

y = weight loss by continuous weighing (percent)  
x = weight loss by intermittent weighing (percent)

The root mean square deviation of values computed with this equation, 0.55 percent, is consistent with the expected experimental variations inherent in the test methods.

A previous report (ref. 3) stated that close agreement obtained under these diverse conditions indicates that extreme high vacuum may not be required for preliminary compatibility testing of many materials. The results of this investigation are consistent with the previous work. However, more extensive investigations with particular interest in rates of weight loss at various pressure levels may be necessary before firm conclusions concerning the merits of the two procedures can be drawn.

## REFERENCES

1. Caruso, S. V.; and Looney, W. C.: A Study of the Outgassing and Evaporation Products of Some Materials Upon Exposure to Reduced Pressure. MSFC MTP-P&VE-M-62-7, April 2, 1962.
2. Riehl, W. A.: Considerations on the Evaporation of Materials in Vacuum. Chemical Engineering Program Symposium Series, vol. 59, no. 40, 1963, pp. 103-117.
3. Gayle, J. B.; Caruso, S. V.; and Egger, C. T.: Vacuum Compatibility of Engineering Materials (Solids). MSFC MTP-P&VE-M-63-11, September 16, 1963.
4. Egger, C. T.; and Gayle, J. B.: Cross Check Study of Thermal-Vacuum Weight Loss Determinations for Selected Polymers. NASA TM X-53106, August 13, 1964.
5. Austin, J. G.; and Gayle J. B.: Vacuum Compatibility of Engineering Materials (Liquids and Semi-Solids). NASA TM X-53207, February 5, 1965.

TABLE I. - CONTINUOUS WEIGHING TEST

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature, °C Programmed    Actual	Initial Weight, g	Weight Loss Total, g    %	Minimum Pressure, torr	Figure No.	Run Designation
DC 7170	1.520 x 1.520 x 0.155	5.600	50	0.5162	0.0001	10 <sup>-4</sup>	3	463-29
Silicone Dielectric	1.491 x 1.423 x 0.153	5.136	100	0.4783	0.0006	10 <sup>-6</sup>	4	563-79
Dow Corning Corporation								
Marlex 6002	1.520 x 1.520 x 0.036	4.600	50	0.0744	0.0001	10 <sup>-5</sup>	5	563-40
Polyurethane Dielectric	0.539 x 0.613 x 0.035	0.742	50	0.0111	0.0001	10 <sup>-5</sup>	5	164-8
Phillips Chemical Company	1.520 x 1.520 x 0.036	4.600	100	0.0721	0.0003	10 <sup>-4</sup>	6	463-30
Geon 2046	1.465 x 0.627 x 0.150	2.462	50	0.1801	0.0043	10 <sup>-5</sup>	7	963-9
PVC Dielectric	1.490 x 0.930 x 0.127	3.400	50	0.2303	0.0028	10 <sup>-6</sup>	7	563-48
B. F. Goodrich Chemical Company	1.520 x 1.020 x 0.150	3.900	99	0.3174	0.0317	10 <sup>-5</sup>	8	563-37
Geon 8800	0.936 x 0.973 x 0.305	2.985	50	0.3684	0.0006	10 <sup>-6</sup>	9	664-8
PVC Dielectric	1.520 x 1.140 x 0.305	3.900	100	0.7095	0.0182	10 <sup>-5</sup>	10	563-36
B. F. Goodrich Chemical Company	0.920 x 0.352 x 0.292	1.389	99	0.1172	0.0013	10 <sup>-6</sup>	10	763-9
Estane 5740	1.180 x 1.305 x 0.061	3.383	50	0.1061	0.0006	10 <sup>-6</sup>	11	963-21
Polyurethane Dielectric	1.520 x 1.520 x 0.074	5.100	50	0.1924	0.0011	10 <sup>-5</sup>	11	563-47
B. F. Goodrich Chemical Company	1.520 x 1.520 x 0.074	5.100	97	0.1921	0.0024	10 <sup>-5</sup>	12	463-31
Royaline-R	1.400 x 1.400 x 0.100	4.400	50	0.2290	0.0007	10 <sup>-5</sup>	13	563-45
Polyolefin Dielectric	0.054 x 0.461 x 0.610	0.678	50	0.0325	0.0001	10 <sup>-6</sup>	13	164-10
Raytherm Corporation	1.400 x 1.400 x 0.100	4.400	99	0.2482	0.0028	10 <sup>-6</sup>	14	563-34
Kel-F 81	0.989 x 1.000 x 0.309	3.207	50	0.6259	0.0000	10 <sup>-6</sup>	15	664-3
Fluorocarbon Dielectric	1.400 x 1.400 x 0.300	4.600	100	1.4147	0.0002	10 <sup>-5</sup>	16	563-35
Minnesota Mining & Manufacturing Company								
Tedlar	1.623 x 1.540 x 0.064	5.390	50	0.0201	0.0000	10 <sup>-5</sup>	17	563-76
PVF Dielectric	1.048 x 0.989 x 0.006	2.095	50	0.0083	0.0000	10 <sup>-6</sup>	17	664-13
Du Pont	1.270 x 15.240 x 0.005	38.710	99	0.1304	0.0001	10 <sup>-6</sup>	18	463-25
	1.520 x 3.180 x 0.005	9.700	100	0.0392	0.0000	10 <sup>-4</sup>	18	563-33
	1.270 x 15.240 x 0.005	38.710	87	0.1159	0.0003	10 <sup>-4</sup>	18	463-24
Teflon FEP	0.714 x 0.384 x 0.103	0.775	50	0.0566	0.0000	10 <sup>-6</sup>	19	164-11
Fluoroethylene Film	0.890 x 1.080 x 0.380	2.200	101	0.1884	0.0000	10 <sup>-5</sup>	20	563-39
Du Pont								

TABLE I. - CONTINUOUS WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature, °C Programmed    Actual	Initial Weight, g	Weight Loss Total, g    %	Minimum Pressure, torr	Figure No.	Run Designation
Duroid 5600	1.000 x 0.989 x 0.314	3.227	50	0.6336	0.0007	10 <sup>-6</sup>	21	664-1
Teflon-glass Dielectric Rogers Corporation	1.680 x 1.680 x 0.460	8.700	100	2.6509	0.0040	10 <sup>-5</sup>	22	563-38
Acrylic Coat	2.413 Dia. (Al disc)	4.580	50	1.2876	0.0003	10 <sup>-4</sup>	23	563-46
Thermal Control Coating Sherwin-Williams Company	2.401 Dia. (Al disc)	4.140	100	0.3120	0.0004	10 <sup>-6</sup>	24	963-2
Silicone Thermal Coating Thermal Control Coating W. P. Fuller Company	2.410 Dia. (Al disc)	4.580	50	1.3515	0.0012	10 <sup>-5</sup>	25	563-49
RTV-60	0.915 x 0.947 x 0.095	2.087	50	0.1222	0.0001	10 <sup>-6</sup>	27	364-24
Silicone Potting Compound General Electric Company	0.081 x 0.520 x 0.555	0.749	100	0.0487	0.0007	10 <sup>-6</sup>	28	164-5
	0.570 x 0.760 x 0.356	2.000	100	0.2232	0.0026	10 <sup>-6</sup>	28	563-51
RTV-501	2.794 (Dia.) x 0.310	14.900	50	2.2111	0.0192		29	563-53
Silicone Potting Compound Dow Corning Corporation	2.790 (Dia.) x 0.310	14.820	50	2.7146	0.0173	10 <sup>-4</sup>	30	563-54
		0.807	50	0.3019	0.0016	10 <sup>-6</sup>	30	763-21
RTV-601		0.807	100	0.2564	0.0031	10 <sup>-6</sup>	31	763-5
Silicone Potting Compound Dow Corning Corporation		0.807	100	0.3105	0.0042	10 <sup>-6</sup>	31	963-1
		0.807	100	0.3229	0.0047	10 <sup>-6</sup>	31	963-22
	0.826 x 0.508 x 0.318	9.309	100	0.1619	0.0019	10 <sup>-4</sup>	31	563-55
DCR-7521	1.239 (Dia.) x 0.550	4.540	50	0.7481	0.0006		32	563-56
Silicone Potting Compound Dow Corning Corporation	1.232 (Dia.) x 0.476	4.220	100	0.4561	0.0039	10 <sup>-4</sup>	33	563-57
EC 2273	1.235 x 1.215 x 0.725	6.560	50	1.3668	0.0104	10 <sup>-4</sup>	34	563-58
Potting Compound	1.483 x 0.188 x 0.066	0.779	50	0.0957	0.0001	10 <sup>-5</sup>	34	1263-1
Minnesota Mining & Manufacturing Company	1.041 x 1.042 x 0.357	3.646	50	0.4463	0.0035	10 <sup>-6</sup>	34	664-7
	0.066 x 0.817 x 0.704	1.354	100	0.0467	0.0013	10 <sup>-5</sup>	35	963-31
	1.045 x 1.055 x 0.354	3.692	100	0.4363	0.0105	10 <sup>-5</sup>	35	664-9

TABLE I. - CONTINUOUS WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature, °C Programmed Actual	Initial Weight, g	Weight Loss Total, g %	Minimum Pressure, torr	Figure No.	Run Designation
Durock D-133	0.526 x 0.558 x 0.550	1.691	50	0.6559	0.0002	10 <sup>-3</sup>	36	563-61
Silico-ceramic Potting Compound	0.510 x 0.550 x 0.433	1.482	100	0.4197	0.0001	0.03	37	563-60
Physical Sciences Corporation								
FM-47	0.944 x 0.957 x 0.036	1.944	50	0.0296	0.0002	10 <sup>-7</sup>	38	364-17
Vinyl-phenolic Adhesive	0.967 x 0.991 x 0.035							
*Bloomington Division,	0.965 x 0.963 x 0.035	6.027	50	0.0937	0.0009	10 <sup>-6</sup>	38	764-9
American Cyanamid Company	0.956 x 0.963 x 0.036							
	1.580 x 0.910 x 0.023	2.984	100	0.0306	0.0001	10 <sup>-5</sup>	39	963-4
Paraplex P-43	1.222 x 0.567 x 0.321	1.500	50	0.3289	0.0012	10 <sup>-4</sup>	40	563-64
Polyester-glass Laminate	0.325 x 1.031 x 1.268	2.759	50	0.6346	0.0005	10 <sup>-6</sup>	40	963-25
Rohm and Haas Company	0.318 x 0.122 x 0.274	1.010	100	0.1435	0.0029	2.03	41	563-65
	0.998 x 0.990 x 0.324	3.264	100	0.4608	0.0120	2.60	41	664-11
CTL-91-LD	1.149 x 0.855 x 0.325	3.270	50	0.4942	0.0044	10 <sup>-5</sup>	42	563-67
Phenolic Laminate	1.066 x 0.476 x 0.328	2.027	100	0.2753	0.0049	1.78	43	563-66
Coast Manufacturing Company	1.335 x 0.394 x 0.292	2.061	100	0.2003	0.0031	1.55	43	1063-6
Epon 828	1.322 x 0.653 x 0.314	2.979	50	0.4436	0.0007	10 <sup>-5</sup>	44	563-69
Epoxy Laminate	1.000 x 0.990 x 0.309	3.210	50	0.5321	0.0004	10 <sup>-6</sup>	44	664-2
Shell Chemical Corporation	1.139 x 0.487 x 0.312	2.121	100	0.2964	0.0008	10 <sup>-6</sup>	45	763-10
DC-2104	0.087 x 0.635 x 0.713	1.141	50	0.0460	0.0000	10 <sup>-6</sup>	46	164-9
Silicone Laminate	1.116 x 0.397 x 0.282	1.742	100	0.1353	0.0002	10 <sup>-6</sup>	47	663-3
Dow Corning Corporation								
DC-2106	1.157 x 0.483 x 0.356	2.285	50	0.3091	0.0004	10 <sup>-5</sup>	48	563-71
Silicone Laminate	0.735 x 0.846 x 0.360	2.382	50	0.3362	0.0004	10 <sup>-6</sup>	48	164-6
Dow Corning Corporation	1.133 x 0.392 x 0.357	2.087	100	0.2530	0.0008	10 <sup>-6</sup>	49	563-70
	0.373 x 0.368 x 0.783	1.434	100	0.1472	0.0003	10 <sup>-6</sup>	49	963-30
	0.467 x 1.646 x 1.628	8.410	150	1.8891	0.0016	0.08	49	363-6
HRP Honeycomb								
Phenolic Laminate			50	0.1493	0.0016	10 <sup>-5</sup>	50	563-72
Applied Plastics Company, Incorporated			100	0.1402	0.0018	10 <sup>-5</sup>	51	563-73

\* Three items used to attain required sample weight.

TABLE I. - CONTINUOUS WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature, °C Programmed Actual	Initial Weight, g	Weight Loss Total, g %	Minimum Pressure, torr	Figure No.	Run Designation
Viton B A495VA								
Rubber	1.580 (Dia.) x 0.254	5.170	50	0.2213	0.0002	10 <sup>-5</sup>	52	563-74
R-PeVE-MN			100	1.1158	0.0007	10 <sup>-6</sup>	53	263-1
Marshall Space Flight Center			200	1.1121	0.0127	10 <sup>-6</sup>	53	363-3
	1.580 (Dia.) x 0.254	5.170	150	1.0999	0.0018	10 <sup>-6</sup>	53	263-2
PRP 73770								
Acrylo-nitrile Elastomer	1.290 x 1.310 x 0.184	4.434	50	0.4126	0.0083	10 <sup>-5</sup>	54	563-77
Precision Rubber Products Corporation	0.632 x 1.332 x 0.179	2.389	100	0.2005	0.0221	10 <sup>-6</sup>	55	563-78
	0.956 x 0.632 x 0.191	1.814	100	0.1434	0.0152	10 <sup>-6</sup>	55	763-17
PRP 8187								
Elastomer	1.442 x 1.295 x 0.186	4.755	50	0.4483	0.0018	10 <sup>-5</sup>	56	563-80
Precision Rubber Products Corporation	1.320 x 0.426 x 0.184	1.768	100	0.0937	0.0055	10 <sup>-5</sup>	57	563-81
	0.193 x 0.625 x 1.282	2.190	100	0.1874	0.0108	10 <sup>-5</sup>	57	963-3
Urethane DS-620								
Urethane Thermal Insulation	1.295 x 1.210 x 0.752	6.902	50	0.0488	0.0019	10 <sup>-8</sup>	58	464-5
American Latex Products								
Ecofoam Q								
Ceramic Thermal Insulation	1.946 x 1.220 x 0.667	8.980	50	0.2886	0.0004	10 <sup>-5</sup>	60	663-5
Emerson & Cuming, Incorporated	1.160 x 1.117 x 1.050	7.373	50	0.2768	0.0001	10 <sup>-6</sup>	60	564-4
	1.225 x 1.215 x 1.186	8.765	100	0.2999	0.0001	10 <sup>-6</sup>	61	564-5
Refrasil B-100								
SiO <sub>2</sub> -glass Thermal Insulation	1.910 x 1.370 x 0.199	6.535	50	0.0803	0.0005	10 <sup>-6</sup>	62	663-9
H. I. Thompson Company	*{0.967 x 0.952 x 0.277							
	*{0.923 x 0.912 x 0.277	8.310	50	0.0773	0.0003	10 <sup>-6</sup>	62	764-18
	0.924 x 0.913 x 0.277							
	1.628 x 1.349 x 0.286	6.075	100	0.0699	0.0006	10 <sup>-5</sup>	63	663-8
	*{1.055 x 0.985 x 0.278							
	*{0.975 x 0.909 x 0.277	8.986	100	0.0823	0.0008	10 <sup>-6</sup>	63	764-20
	*{0.967 x 0.971 x 0.277							
CPR-20								
Polyurethane Thermal Insulation	2.420 x 1.320 x 0.840	12.680	50	0.1875	0.0031	10 <sup>-5</sup>	64	663-10
Chemical Products Company	0.532 x 0.631 x 0.708	2.319	50	0.0147	0.0002	10 <sup>-6</sup>	64	164-13

\* Three items used to attain required sample weight.

TABLE I. - CONTINUOUS WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature, °C Programmed Actual	Initial Weight, g	Weight Loss Total, g %	Minimum Pressure, torr	Figure No.	Run Designation
CPR-1021	2.140 x 1.182 x 1.170	12.830	50	0.0996	0.0026 2.62	10 <sup>-5</sup>	66	663-12
Polyurethane Thermal Insulation	2.540 x 2.540 x 2.540	38.712	50	0.4342	0.0087 2.20	10 <sup>-6</sup>	66	363-16
Chemical Products Company	2.540 x 2.540 x 2.540	38.712	100	0.4343	0.0067 1.54	10 <sup>-6</sup>	67	363-17
Duroid 5813	0.749 x 0.473 x 0.437	1.780	50	0.3608	0.0002 0.06	10 <sup>-5</sup>	68	663-7
Teflon-glass	0.505 x 0.437 x 0.397	1.290	100	0.2018	0.0001 0.05	10 <sup>-6</sup>	69	663-6
Rogers Corporation								
Epon VIII	(1.005 x 0.985 x 0.020							
Epoxy Adhesive	*{1.035 x 0.987 x 0.020							
Shell Chemical Corporation	{0.996 x 0.979 x 0.020	6.213	50	0.0637	0.0003 0.47	10 <sup>-6</sup>	70	764-15
	(1.014 x 1.017 x 0.023							
	*{1.021 x 1.027 x 0.017	6.394	100	0.0660	0.0013 1.97	10 <sup>-6</sup>	71	764-13
	{1.008 x 0.988 x 0.020							
APCO 1252	1.881 x 1.465 x 0.027	5.688	50	0.0665	0.0001 0.16	10 <sup>-4</sup>	72	663-16
Polyurethane Adhesive	0.959 x 0.981 x 0.029	1.995	50	0.0219	0.0001 0.45	10 <sup>-8</sup>	72	364-23
Hexcel Corporation	{0.996 x 0.910 x 0.063	4.077	100	0.0675	0.0011 1.63	10 <sup>-6</sup>	73	764-3
	**{0.989 x 0.926 x 0.030							
Shell 929	1.525 x 1.182 x 0.125	4.266	50	0.2960	0.0015 0.53	10 <sup>-4</sup>	74	663-18
Epoxy Adhesive	1.143 x 0.957 x 0.113	2.664	100	0.1657	0.0024 1.45	10 <sup>-6</sup>	75	663-21
Shell Chemical Corporation								
Shell 934	1.608 x 1.472 x 0.652	5.143	50	0.2495	0.0012 0.48	10 <sup>-4</sup>	76	663-20
Epoxy Adhesive	1.004 x 1.081 x 0.079	5.465	50	0.1085	0.0007 0.65	10 <sup>-6</sup>	76	664-5
Shell Chemical Corporation	1.234 x 0.564 x 0.085	1.680	100	0.0750	0.0006 0.80		77	663-19
	1.219 x 1.105 x 0.089	3.110	100	0.1548	0.0020 1.31	10 <sup>-5</sup>	77	963-7
Narmco "A" 3170-7133	1.571 x 1.331 x 0.070	4.576	50	0.1474	0.0019 1.29	10 <sup>-5</sup>	80	663-25
Modified Epoxy Adhesive								
Narmco Industries								

\* Three items used to attain required sample weight.

\*\* Two items used to attain required sample weight.



TABLE I. - CONTINUOUS WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature, °C Programmed Actual	Initial Weight, g	Weight Loss Total, g %	Minimum Pressure, torr	Figure No.	Run Designation
Narmco "C" 7343-7139 Polyurethane Adhesive Narmco Industries	0.964 x 0.955 x 0.054 1.121 x 0.659 x 0.052	2.047 1.663	50 50	0.0458 0.0392	0.0004 0.87 0.0004 1.03	10 <sup>-8</sup> 10 <sup>-6</sup>	82 82	364-19 1263-6
Aerobond 430 Epoxy-phenolic Adhesive Adhesive Engineering Company	1.396 x 0.893 x 0.024 0.988 x 0.978 x 0.025 0.986 x 0.957 x 0.028 * 0.974 x 0.996 x 0.026 * 0.993 x 0.939 x 0.026	0.858 2.030 5.985	50 50 50	0.0358 0.0282 0.0859	0.0003 0.85 0.0001 0.35 0.0006 0.70	10 <sup>-6</sup> 10 <sup>-6</sup> 10 <sup>-8</sup>	84 84 84	1263-11 664-14 764-10
FM-1000 Epoxy-nylon Adhesive Bloomington Division, American Cyanamid Company	0.035 x 0.716 x 0.616 ** 0.995 x 0.969 x 0.027 ** 0.943 x 0.944 x 0.027	0.975 3.837	100 100	0.0135 0.0537	0.0003 2.23 0.0015 2.79	10 <sup>-6</sup> 10 <sup>-5</sup>	87 87	1163-2 764-1
AF-6 Nitrile-phenolic Adhesive Minnesota Mining & Manufacturing Company	1.650 x 0.616 x 0.013	2.087	100	0.0170	0.0008 4.71	10 <sup>-6</sup>	91	763-1
AF-40 Epoxy-nylon Adhesive Minnesota Mining & Manufacturing Company	1.715 x 1.215 x 0.046 1.621 x 0.452 x 0.025	4.438 1.563	50 100	0.0491 0.0191	0.0008 1.63 0.0002 1.05	10 <sup>-6</sup> 10 <sup>-3</sup>	92 93	763-16 763-2
Narmco 4021 Nitrile-phenolic Adhesive Narmco Industries	0.978 x 0.958 x 0.031 * 0.968 x 0.960 x 0.027 0.948 x 0.925 x 0.026 1.612 x 0.423 x 0.071	5.806 1.648	50 100	0.0678 0.0308	0.0012 1.77 0.0012 3.90	10 <sup>-7</sup> 10 <sup>-6</sup>	94 95	764-6 763-3
Narmco 408 Modified Epoxy Narmco Industries	1.324 x 0.708 x 0.019 1.085 x 0.983 x 0.019	1.951 2.210	100 100	0.0173 0.0185	0.0004 2.32 0.0003 2.62	10 <sup>-6</sup> 10 <sup>-8</sup>	97 97	763-4 464-7

\* Three items used to attain required sample weight.

\*\* Two items used to attain required sample weight.

TABLE I. - CONTINUOUS WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature, °C Programmed Actual	Initial Weight, g	Weight Loss Total, g %	Minimum Pressure, torr	Figure No.	Run Designation
Selctron 5003	1.648 x 0.787 x 0.259	3.851	50	0.6114	0.0003	10 <sup>-6</sup>	98	763-23
Polyester Laminate	1.540 x 0.566 x 0.261	2.732	100	0.4194	0.0017	10 <sup>-6</sup>	99	763-6
Pittsburgh Plate Glass Company								
Kynar	{1.019 x 1.006 x 0.017							
Fluoroethylene Dielectric	*{1.031 x 0.996 x 0.016	6.201	50	0.0800	0.0000	10 <sup>-8</sup>	100	764-16
Pennsalt Chemical Corporation	{0.983 x 0.967 x 0.016							
	{0.980 x 0.987 x 0.017							
	*{0.993 x 0.989 x 0.017	5.981	100	0.0795	0.0001	10 <sup>-7</sup>	100	764-17
	{0.971 x 0.969 x 0.017							
MB 406	1.005 x 0.982 x 0.025	2.073	50	0.0215	0.0004	10 <sup>-8</sup>	104	364-16
Epoxy-phenolic Adhesive								
Narmco Industries								
MB 4021	1.332 x 1.635 x 0.025	5.510	50	0.0506	0.0015	10 <sup>-6</sup>	106	963-23
Nitrile-phenolic Adhesive	0.745 x 0.616 x 0.028	0.992	100	0.0112	0.0004	10 <sup>-6</sup>	107	1063-11
Narmco Industries								
Scotchcast 212	0.297 x 0.838 x 1.028	2.830	50	0.2979	0.0013	10 <sup>-6</sup>	108	963-16
Epoxy Potting Compound	1.068 x 0.304 x 0.299	1.473	100	0.1041	0.0024	10 <sup>-6</sup>	109	963-17
Minnesota Mining & Manufacturing Company								
EC-1949	1.329 x 0.927 x 0.152	3.364	50	0.2267	0.0024	10 <sup>-6</sup>	110	763-26
Epoxy Potting Compound	0.828 x 0.793 x 0.117	1.692	100	0.0955	0.0030	10 <sup>-6</sup>	111	763-27
Minnesota Mining & Manufacturing Company								
EC-1663	0.966 x 0.994 x 0.200	2.704	50	0.2828	0.0021	10 <sup>-6</sup>	112	764-7
Epoxy Potting Compound	0.858 x 0.508 x 0.181	1.367	100	0.1191	0.0011	10 <sup>-6</sup>	113	963-11
Minnesota Mining & Manufacturing Company								
PR-1538	1.200 x 0.866 x 0.277	3.225	50	0.3542	0.0013	10 <sup>-6</sup>	114	963-19
Polyurethane Potting Compound	0.272 x 0.526 x 0.520	1.116	100	0.0876	0.0008	10 <sup>-6</sup>	115	963-18
Products Research Company								

\* Three items used to attain required sample weight.

TABLE I. - CONTINUOUS WEIGHING TEST (Concluded)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature, °C Programmed Actual	Initial Weight, g	Weight Loss Total, g %	Minimum Pressure, torr	Figure No.	Run Designation
Electrofilm 66-C			50	0.0339	0.0000	10 <sup>-6</sup>	118	763-32
MoS <sub>2</sub> Lubricant			50	0.0184	0.0000	10 <sup>-8</sup>	118	864-4
Electrofilm Corporation			100	0.0177	0.0001	10 <sup>-8</sup>	119	864-3
MLF-5	1.781 (Dia.) x 0.163	2.939	50	0.4821	0.0003	10 <sup>-6</sup>	120	963-14
MoS <sub>2</sub> Lubricant	1.781 (Dia.) x 0.163	1.474	100	0.2202	0.0002	10 <sup>-6</sup>	121	963-15
Midwest Research, Incorporated								
ETR-H	50	54	50	0.1697	0.0012	10 <sup>-6</sup>	122	863-2
Silicone Lubricant								
General Electric Company								
Epoxy Coating (on Aluminum)	2.412 Dia. (Al disc)	4.566	50	1.3748	0.0005	10 <sup>-7</sup>	124	764-21
Thermal Control Coating	2.415 Dia. (Al disc)	4.612	100	1.3624	0.0020	10 <sup>-7</sup>	125	764-19
Andrew Brown Company								
Epoxy Coating (off Glass)	0.953 x 0.983 x 0.030	1.990	50	0.0779	0.0006	10 <sup>-6</sup>	126	764-8
Thermal Control Coating	0.021 x 0.662 x 0.984	2.021	100	0.0191	0.0010	10 <sup>-6</sup>	127	1163-3
Andrew Brown Company								
Merlon	0.983 x 1.057 x 0.154	2.772	50	0.1871	0.0002	10 <sup>-8</sup>	128	364-33
Polycarbonate Insulator	0.982 x 1.062 x 0.153	2.711	50	0.1870	0.0002	10 <sup>-8</sup>	128	364-34
Mobay Chemical Company	0.976 x 1.036 x 0.154	2.631	140	0.1809	0.0004	10 <sup>-7</sup>	129	464-1
	0.985 x 0.934 x 0.153	2.450	140	0.1613	0.0004	10 <sup>-7</sup>	129	464-4

TABLE II. - INTERMITTENT WEIGHING TEST

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature °C	Initial Weight g	Weight Loss Total, g	Figure No.	Run Designation
DC 7170 Silicone Dielectric Dow Corning Corporation	1.444 x 1.062 x 0.154	3.839	50	0.3292	-0.0005*	3	A
	1.524 x 1.524 x 0.155	5.593	100	0.5006	0.0003	4	A
Marlex 6002 Polyurethane Dielectric Phillips Chemical Company	1.382 x 1.029 x 0.035	3.013	50	0.0460	0.0002	5	A
	1.524 x 1.524 x 0.036	4.867	100	0.0745	0.0004	6	A
Geon 2046 PVC Dielectric B. F. Goodrich Chemical Company	1.420 x 1.071 x 0.130	3.690	50	0.2607	0.0185	7	A
	1.524 x 1.524 x 0.150	5.562	100	0.3797	0.0883	8	A
Geon 8800 PVC Dielectric B. F. Goodrich Chemical Company	1.532 x 1.169 x 0.306	5.235	50	0.7186	0.0000	9	A
	1.524 x 1.143 x 0.300	5.084	100	0.7046	0.0125	10	A
Estane 5740 Polyurethane Dielectric B. F. Goodrich Chemical Company	1.080 x 1.308 x 0.051	3.069	50	0.0845	0.0005	11	A
	1.524 x 1.524 x 0.074	5.099	100	0.1879	0.0025	12	A
Royaline-R Polyolefin Dielectric Raytherm Corporation	1.372 x 1.052 x 0.106	3.401	50	0.1735	0.0004	13	A
	1.400 x 1.400 x 0.104	4.502	100	0.2343	0.0028	14	A
Kel-F 81 Fluorocarbon Dielectric Minnesota Mining & Manufacturing Company	1.370 x 1.170 x 0.309	4.776	50	0.9989	0.0002	15	A
	1.400 x 1.400 x 0.310	5.656	100	1.3480	0.0002	16	A
Teflon FEP Fluoroethylene Film Du Pont	1.375 x 1.052 x 0.098	3.369	50	0.2932	0.0001	19	A
	1.524 x 1.524 x 0.099	5.252	100	0.4506	0.0000	20	A
Duroid 5600 Teflon-glass Dielectric Rogers Corporation	1.440 x 1.085 x 0.785	7.039	50	2.5340	0.0017	21	A
	1.651 x 1.651 x 0.462	6.978	100	2.5597	0.0028	22	A
				1.9800	0.0026		B

\* Weight Gain.

TABLE II. - INTERMITTENT WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature °C	Initial Weight g	Weight Loss,		Figure No.	Run Designation
					Total, g	%		
Acrylic Coat Thermal Control Coating Sherwin-Williams Company	2.405 Dia. (Al disc)	4.555	50	1.2846	0.0004	0.04	23	A
	2.413 Dia. (Al disc)	4.572	100	1.2854	0.0013	0.10	24	A
Silicone Thermal Coating Thermal Control Coating W. P. Fuller Company	2.413 Dia. (Al disc)	4.572	50	1.3552	0.0001	0.03	25	A
	2.413 Dia. (Al disc)	4.572	100	1.3757	0.0038	0.28	26	A
RTV-60 Silicone Potting Compound General Electric Company	1.214 x 0.991 x 0.086	2.785	50	0.1552	0.0011	0.72	27	A
			100	0.4500	0.0043	0.96	28	A
RTV-501 Silicone Potting Compound Dow Corning Corporation	1.036 x 0.994 x 0.314	3.335	50	0.3860	0.0040	1.07	29	A
	[1.250 (Dia.) x 0.317] ÷ 4	4.640	50	0.6056	0.0084	1.40	29	B
RTV-601 Silicone Potting Compound Dow Corning Corporation	1.125 x 0.912 x 0.309	3.311	50	0.3905	0.0018	0.50	30	A
			50	0.3857	0.0023	0.63	30	B
	2.794 (Dia.) x 0.325	15.109	100	2.6860	0.0329	1.22	31	A
			100	0.9790	0.0123	1.27	31	B
	2.858 (Dia.) x 0.305	15.571	100	2.6289	0.0347	1.33	31	C
			100	0.3145	0.0040	1.30	31	D
DCR-7521 Silicone Potting Compound Dow Corning Corporation	1.240 (Dia.) x 0.572	4.641	100	0.7662	0.0102	1.33	33	A
EC 2273 Potting Compound Minnesota Mining & Manufacturing Company	3.548 x 2.042 x 0.051	15.060	50	0.0829	0.0010	1.22	34	A
Durock D-133 Silico-ceramic Potting Compound Physical Sciences Corporation	1.396 (Dia.) x 0.560 1.397 (Dia.) x 0.762	5.512 6.407	50 100	3.8907 5.1846	0.0001 0.0000	0.02 0.00	36 37	A B

TABLE II. - INTERMITTENT WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature °C	Initial Weight g	Weight Loss, Total, g	Figure No.	Run Designation
FM-47	1.232 x 1.275 x 0.025	3.267	50	0.0379	0.0006	1.61	38 A
Vinyl-phenolic Adhesive	3.117 x 1.788 x 0.079	11.921	50	0.0240	0.0003	1.26	38 B
Bloomington Division,	1.410 x 1.346 x 0.020	3.906	100	0.0434	0.0007	1.62	39 B
American Cyanamid Company	2.403 x 1.623 x 0.079	8.436	100	0.0175	0.0003	1.72	39 C
Paraplex P-43	1.377 x 1.220 x 0.321	3.527	50	0.8138	0.0026	0.39	40 A
Polyester-glass Laminate							
Rohm and Haas Company							
CTL-91-LD	1.349 x 1.205 x 0.332	4.947	50	0.8996	0.0125	1.45	42 A
Phenolic Laminate	1.270 x 1.905 x 0.330	6.935	100	1.2548	0.0232	1.85	43 A
Coast Manufacturing Company							
Epon 828	1.376 x 1.129 x 0.315	4.685	50	0.8457	0.0016	0.23	44 A
Epoxy Laminate	2.540 x 1.118 x 0.318	8.005	100	1.5504	0.0043	0.28	45 A
Shell Chemical Corporation							
DC-2104	1.288 x 1.295 x 0.102	3.863	50	0.1754	0.0004	0.24	46 A
Silicone Laminate	2.540 x 1.270 x 0.254	8.387	100	1.0600	0.0017	0.14	47 A
Dow Corning Corporation							
DC-2106	1.407 x 1.155 x 0.360	5.095	50	0.9246	0.0017	0.24	48 A
Silicone Laminate	1.270 x 1.905 x 0.292	8.331	100	1.3300	0.0036	0.27	49 A
Dow Corning Corporation							
HRP Honeycomb	1.508 x 1.190 x 0.353	5.494	50	0.0939	0.0008	0.95	50 A
Phenolic Laminate			50	0.3124	0.0033	1.06	50 B
Applied Plastics Company,			100	0.7047	0.0066	0.94	51 A
Incorporated			100	0.2849	0.0032	1.06	51 B
Viton B A495VA	1.270 (Dia.) x 0.339	3.855	50	0.2358	0.0003	0.15	52 A
Rubber	3.302 (Dia.) x 0.267	27.488	100	1.7843	0.0022	0.12	53 A
R-P&VE-MN			100	1.7525	0.0029	0.17	53 B
Marshall Space Flight Center	1.151 (Dia.) x 0.343	3.324	100	0.2070	0.0003	0.17	53 C

TABLE II. - INTERMITTENT WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature °C	Initial Weight g	Weight Loss Total, g	Figure No.	Run Designation
PRP 73770 Acrylo-nitrile Elastomer Precision Rubber Products Corporation	1.180 x 1.017 x 0.190	3.235	50	0.2888	0.0256	54	A
	1.270 x 1.334 x 0.191	4.383	100	0.4215	0.0490	55	A
PRP 8187 Elastomer Precision Rubber Products Corporation	1.154 x 1.171 x 0.193	3.600	50	0.2841	0.0086	56	A
	1.397 x 1.334 x 0.191	4.770	100	0.4455	0.0270	57	A
Urethane DS-620 Urethane Thermal Insulation American Latex Products	1.135 x 1.280 x 1.232	8.857	50	0.0631	0.0030	58	A
			100	0.1076	0.0047	59	A
	1.207 x 1.069 x 0.691	5.726	100	0.0361	0.0018	59	B
Eccofoam Q Ceramic Thermal Insulation Emerson & Cuming, Incorporated	1.257 x 1.280 x 0.912	7.845	50	0.2691	0.0006	60	A
			100	0.7256	0.0016	61	A
Refrasil B-100 SiO <sub>2</sub> -glass Thermal Insulation H. I. Thompson Company	1.301 x 0.985 x 0.237	3.647	50	0.0386	0.0001	62	A
	2.667 x 3.592 x 0.729	28.286	50	0.0345	0.0001	62	B
			100	0.1923	0.0002	63	A
	1.567 x 3.818 x 1.074	23.533	100	0.0269	0.0003	63	B
CPR-20 Polyurethane Thermal Insulation Chemical Products Company	1.347 x 0.889 x 0.802	5.981	50	0.0538	0.0011	64	A
			100	0.8866	0.0193	65	A
	1.285 x 1.214 x 0.655	6.394	100	0.0535	0.0016	65	B
CPR-1021 Polyurethane Thermal Insulation Chemical Products Company	4.440 x 2.578 x 1.588	45.182	50	0.0333	0.0014	66	B
			100	1.0892	0.0365	67	A
	2.390 x 4.178 x 1.613	41.159	100	0.0351	0.0017	67	B
Duroid 5813 Teflon-glass Rogers Corporation	1.220 x 1.046 x 0.437	4.532	50	1.3016	0.0006	68	A
	1.267 x 1.207 x 0.445	5.261	100	1.5462	0.0005	69	A

TABLE II. - INTERMITTENT WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature °C	Initial Weight g	Weight Loss Total, g	Figure No.	Run Designation
Epon VIII Epoxy Adhesive Shell Chemical Corporation	1.521 x 1.006 x 0.028	3.202	50	0.0390	0.0005	70	A
			100	0.1270	0.0014	71	A
APCO 1252 Polyurethane Adhesive Hexcel Corporation	1.514 x 1.529 x 0.038 1.300 x 1.341 x 0.041	4.861 3.704	50	0.0560	0.0000	72	A
			100	0.0497	0.0002	73	A
Shell 929 Epoxy Adhesive Shell Chemical Corporation	1.529 x 1.468 x 0.127 1.339 x 1.356 x 0.132	5.250 4.342	50	0.0869	0.0018	73	B
			100	0.3770	0.0058	74	A
Shell 934 Epoxy Adhesive Shell Chemical Corporation	1.468 x 1.476 x 0.089 1.359 x 1.313 x 0.081	4.840 4.002	50	0.3447	0.0032	75	A
			100	0.3164	0.0067	75	B
HT-424 Epoxy-phenolic Adhesive Bloomington Division, American Cyanamid Company	1.420 x 1.422 x 0.028 1.402 x 1.720 x 0.028	4.197 4.998	50	0.2510	0.0027	76	A
			100	0.1844	0.0013	77	A
Narmco "A" 3170-7133 Modified Epoxy Adhesive Narmco Industries	1.433 x 1.461 x 0.069 1.328 x 1.337 x 1.211 1.253 x 1.291 x 0.634 1.262 x 1.327 x 0.237	4.586 10.006 6.461 4.576	50	0.1825	0.0024	77	B
			100	0.0652	0.0003	78	A
Narmco "C" 7343-7139 Polyurethane Adhesive Narmco Industries	1.276 x 1.321 x 0.156 1.466 x 1.422 x 0.056	4.181 4.492	50	0.1623	0.0013	79	A
			100	0.0787	0.0004	79	B
Narmco "A" 3170-7133 Modified Epoxy Adhesive Narmco Industries	1.433 x 1.461 x 0.069 1.328 x 1.337 x 1.211 1.253 x 1.291 x 0.634 1.262 x 1.327 x 0.237	4.586 10.006 6.461 4.576	50	0.1168	0.0021	80	A
			100	2.1704	0.0147	81	A
Narmco "C" 7343-7139 Polyurethane Adhesive Narmco Industries	1.268 x 1.326 x 0.038 1.381 x 1.405 x 1.166 1.290 x 1.308 x 0.670 1.243 x 1.321 x 0.674 1.692 x 1.445 x 0.053	3.560 10.378 6.856 6.740 5.223	100	0.9863	0.0100	81	B
			100	0.4123	0.0075	81	C
Narmco "C" 7343-7139 Polyurethane Adhesive Narmco Industries	1.268 x 1.326 x 0.038 1.381 x 1.405 x 1.166 1.290 x 1.308 x 0.670 1.243 x 1.321 x 0.674 1.692 x 1.445 x 0.053	3.560 10.378 6.856 6.740 5.223	100	0.2722	0.0063	81	D
			100	0.2653	0.0063	81	E
Narmco "C" 7343-7139 Polyurethane Adhesive Narmco Industries	1.268 x 1.326 x 0.038 1.381 x 1.405 x 1.166 1.290 x 1.308 x 0.670 1.243 x 1.321 x 0.674 1.692 x 1.445 x 0.053	3.560 10.378 6.856 6.740 5.223	50	0.1182	0.0008	82	A
			100	0.2085	0.0025	82	A
Narmco "C" 7343-7139 Polyurethane Adhesive Narmco Industries	1.268 x 1.326 x 0.038 1.381 x 1.405 x 1.166 1.290 x 1.308 x 0.670 1.243 x 1.321 x 0.674 1.692 x 1.445 x 0.053	3.560 10.378 6.856 6.740 5.223	100	2.3757	0.0260	83	B
			100	0.0677	0.0011	83	C
Narmco "C" 7343-7139 Polyurethane Adhesive Narmco Industries	1.268 x 1.326 x 0.038 1.381 x 1.405 x 1.166 1.290 x 1.308 x 0.670 1.243 x 1.321 x 0.674 1.692 x 1.445 x 0.053	3.560 10.378 6.856 6.740 5.223	100	1.2086	0.0131	83	D
			100	0.1811	0.0021	83	E
Narmco "C" 7343-7139 Polyurethane Adhesive Narmco Industries	1.268 x 1.326 x 0.038 1.381 x 1.405 x 1.166 1.290 x 1.308 x 0.670 1.243 x 1.321 x 0.674 1.692 x 1.445 x 0.053	3.560 10.378 6.856 6.740 5.223	100	0.1218	0.0018	83	F
			100	0.1218	0.0018	83	F



TABLE II. - INTERMITTENT WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature °C	Initial Weight g	Weight Loss Total, g	%	Figure No.	Run Designation
Aerobond 430	1.476 x 1.430 x 0.023	4.355	50	0.0604	0.0004	0.67	84	A
Epoxy-phenolic Adhesive	1.430 x 1.720 x 0.030	5.108	100	0.0706	0.0003	0.46	85	A
Adhesive Engineering Company	1.775 x 1.374 x 0.028	5.054	100	0.0774	0.0006	0.86	85	B
			100	0.2135	0.0020	0.94	85	C
FM-1000	1.473 x 1.493 x 0.025	4.546	50	0.0657	0.0015	2.29	86	A
Epoxy-nylon Adhesive	1.361 x 1.220 x 0.027	3.460	50	0.0504	0.0011	2.19	86	B
Bloomington Division,	2.070 x 3.825 x 0.066	16.614	50	0.0377	0.0006	1.60	86	C
American Cyanamid Company	1.727 x 1.334 x 0.038	4.841	100	0.0678	0.0011	1.69	87	A
	2.388 x 3.607 x 0.066	18.018	100	0.0397	0.0008	2.02	87	C
Narmco 302A	1.483 x 1.443 x 0.018	5.322	50	0.0455	0.0002	0.44	88	A
Epoxy-phenolic Adhesive	2.699 x 2.159 x 0.206	13.655	100	0.1389	0.0012	0.87	89	A
Narmco Industries								
AF-6	1.504 x 1.410 x 0.015	4.328	50	0.0355	0.0010	2.92	90	A
Nitrile-phenolic Adhesive	3.635 x 2.159 x 0.015	15.870	100	0.1375	0.0070	5.10	91	A
Minnesota Mining & Manufacturing Company								
AF-40	1.483 x 1.476 x 0.030	4.585	50	0.0535	0.0012	2.63	92	A
Epoxy-nylon Adhesive	1.412 x 1.311 x 0.033	3.892	100	0.0458	0.0016	3.52	93	A
Minnesota Mining & Manufacturing Company	3.571 x 2.699 x 0.034	19.602	100	0.2259	0.0090	3.99	93	B
Narmco 4021	1.445 x 1.496 x 0.030	4.529	50	0.0608	0.0013	2.19	94	A
Nitrile-phenolic Adhesive	2.380 x 3.016 x 0.030	14.980	100	0.2211	0.0093	4.21	95	A
Narmco Industries	1.397 x 1.750 x 0.023	5.035	100	0.0381	0.0020	3.46	95	B
	1.410 x 1.717 x 0.028	5.016	100	0.0595	0.0024	4.08	95	C
Narmco 408	1.445 x 1.453 x 0.018	4.303	50	0.0419	0.0007	1.70	96	A
Modified Epoxy	2.707 x 2.065 x 0.170	12.801	100	0.1749	0.0038	2.18	97	A
Narmco Industries								

TABLE II. - INTERMITTENT WEIGHING TEST (Continued)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature °C	Initial Weight g	Weight Loss, Total, g	Figure No.	Run Designation
Selectron 5003 Polyester Laminate Pittsburgh Plate Glass Company	1.306 x 1.778 x 0.257	6.229	50	1.0608	0.0023	98	A
	3.016 x 2.062 x 0.247	14.947	100	2.4658	0.0121	99	A
Kynar Fluoroethylene Dielectric Pennsalt Chemicals Corporation	1.471 x 1.461 x 0.015	4.386	50	0.0588	0.0001	100	A
	4.128 x 2.380 x 0.014	19.831	100	0.1720	0.0002	101	A
MB 302A Epoxy-phenolic Adhesive Narmco Industries	1.349 x 1.854 x 0.025	5.162	50	0.0594	0.0003	102	A
	1.859 x 1.326 x 0.025	5.089	100	0.0595	0.0004	103	A
MB 406 Epoxy-phenolic Adhesive Narmco Industries	1.872 x 1.641 x 0.025	6.320	50	0.0700	0.0012	104	A
	1.681 x 1.572 x 0.025	5.448	100	0.0564	0.0013	105	A
MB 4021 Nitrile-phenolic Adhesive Narmco Industries	1.791 x 1.651 x 0.023	6.072	50	0.0726	0.0021	106	A
	1.676 x 1.862 x 0.030	6.453	100	0.0760	0.0028	107	A
Scotchcast 212 Epoxy Potting Compound Minnesota Mining & Manufacturing Company	1.298 x 1.359 x 0.284	5.037	50	0.5873	0.0034	108	A
	1.364 x 1.488 x 0.290	5.713	100	0.6724	0.0117	109	A
EC 1949 Epoxy Potting Compound Minnesota Mining & Manufacturing Company	1.422 x 1.384 x 0.117	4.593	50	0.3041	0.0073	110	A
	1.367 x 1.740 x 0.157	5.733	100	0.4373	0.0151	111	A
EC 1663 Epoxy Potting Compound Minnesota Mining & Manufacturing Company	1.290 x 1.247 x 0.178	4.120	50	0.4257	0.0031	112	A
	1.488 x 1.311 x 0.175	4.882	100	0.4801	0.0049	113	A

TABLE II. - INTERMITTENT WEIGHING TEST (Concluded)

Material	Sample Dimensions cm	Surface Area cm <sup>2</sup>	Temperature °C	Initial Weight g	Weight Loss Total, g	%	Figure No.	Run Designation
PR-1538 Polyurethane Potting Compound Products Research Company	1.369 x 1.234 x 0.282	4.847	50	0.5655	0.0036	0.66	114	A
	1.245 x 1.506 x 0.284	5.313	100	0.6178	0.0054	0.88	115	A
Molykote X-15 MoS <sub>2</sub> Lubricant Alpha Molykote Corporation			50	0.0322	0.0004	1.25	116	A
			100	0.0363	0.0002	0.88	117	A
Electrofilm 66-C MoS <sub>2</sub> Lubricant Electrofilm Corporation			50	0.0304	0.0003	0.99	118	A
			100	0.0225	0.0002	0.89	119	A
MLF-5 MoS <sub>2</sub> Lubricant Midwest Research, Incorporated	1.760 (Dia.) x 0.163	5.761	50	1.0749	0.0001	0.02	120	A
	1.758 (Dia.) x 0.163	5.754	100	1.0630	0.0002	0.02	121	A
ETR-H Silicone Lubricant General Electric Company			50	0.0540	0.0030	5.56	122	A
			100	0.0236	0.0019	8.06	123	A
Epoxy Coating (on Al) Thermal Control Coating Andrew Brown Company	2.421 (Dia.)	4.615	50	1.3755	0.0009	0.07	124	A
	2.405 (Dial)	4.555	100	1.3641	0.0022	0.17	125	A
Epoxy Coating (off Glass) Thermal Control Coating Andrew Brown Company	0.983 x 0.792 x 0.028	1.656	50	0.0314	0.0004	1.30	126	A
	1.293 x 1.140 x 0.036	3.123	100	0.0646	0.0031	4.81	127	A




FIGURE 1. - CONTINUOUS RECORDING AUTOMATIC ELECTROBALANCE




FIGURE 2. - CERAMIC OVEN FOR HEATING TEST SPECIMENS IN VACUUM




FIGURE 3. - TIME-WEIGHT HISTORIES FOR DC 7170 DURING EXPOSURE TO VACUUM AT 49°C AND 50°C




FIGURE 4. - TIME-WEIGHT HISTORIES FOR DC 7170 DURING EXPOSURE TO VACUUM AT 98°C AND 100°C




FIGURE 5. - TIME-WEIGHT HISTORIES FOR MARLEX 6002 DURING EXPOSURE TO VACUUM AT 50°C AND 53°C






FIGURE 6. - TIME-WEIGHT HISTORIES FOR MARLEX 6002 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 7. - TIME-WEIGHT HISTORIES FOR GEON 2046 DURING EXPOSURE TO VACUUM AT 43°C, 50°C, AND 52°C




FIGURE 8. - TIME-WEIGHT HISTORIES FOR GEON 2046 DURING EXPOSURE TO VACUUM AT 99°C AND 100°C




FIGURE 9. - TIME-WEIGHT HISTORIES FOR GEON 8800 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 10. - TIME-WEIGHT HISTORIES FOR GEON 8800 DURING EXPOSURE TO VACUUM AT 99°C AND 100°C




FIGURE 11. - TIME - WEIGHT HISTORIES FOR ESTANE 5740 DURING EXPOSURE TO VACUUM AT 50°C AND 73°C




FIGURE 12. - TIME-WEIGHT HISTORIES FOR ESTANE 5740 DURING EXPOSURE TO VACUUM AT 97°C AND 100°C




FIGURE 13. - TIME-WEIGHT HISTORIES FOR ROYALINE-R DURING EXPOSURE TO VACUUM  
AT 49°C, 50°C, AND 52°C






FIGURE 14. - TIME-WEIGHT HISTORIES FOR ROYALINE-R DURING EXPOSURE TO VACUUM AT 99°C AND 100°C




FIGURE 15. - TIME-WEIGHT HISTORIES FOR KEL-F 81 DURING EXPOSURE TO VACUUM  
AT 48°C AND 50°C




FIGURE 16. - TIME-WEIGHT HISTORIES FOR KEL-F 81 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 17. - TIME-WEIGHT HISTORIES FOR TEDLAR DURING EXPOSURE TO VACUUM AT 50°C AND 51°C




FIGURE 18. - TIME-WEIGHT HISTORIES FOR TEDLAR DURING EXPOSURE TO VACUUM AT 87°C, 99°C, AND 100°C




FIGURE 19. - TIME-WEIGHT HISTORIES FOR TEFLON FEP DURING EXPOSURE TO VACUUM AT 47°C AND 50°C




FIGURE 20. - TIME-WEIGHT HISTORIES FOR TEFLON FEP DURING EXPOSURE TO VACUUM AT 100°C AND 101°C




FIGURE 21. - TIME-WEIGHT HISTORIES FOR DUROID 5600 DURING EXPOSURE TO VACUUM  
AT 48°C AND 50°C






FIGURE 22. - TIME-WEIGHT HISTORIES FOR DUROID 5600 DURING EXPOSURE TO VACUUM AT 100°C AND 101°C




FIGURE 23. - TIME-WEIGHT HISTORIES FOR ACRYLIC COAT DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 24. - TIME-WEIGHT HISTORIES FOR ACRYLIC COAT DURING EXPOSURE TO VACUUM  
AT 100°C AND 101°C




FIGURE 25. - TIME-WEIGHT HISTORIES FOR SILICONE THERMAL COATING DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 26. - TIME-WEIGHT HISTORIES FOR SILICONE THERMAL COATING DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 27. - TIME-WEIGHT HISTORIES FOR RTV-60 DURING EXPOSURE TO VACUUM AT 47°C AND 50°C




FIGURE 28. - TIME-WEIGHT HISTORIES FOR RTV-60 DURING EXPOSURE TO VACUUM AT 100°C, 102°C, AND 120°C




FIGURE 29. - TIME-WEIGHT HISTORIES FOR RTV-501 DURING EXPOSURE TO VACUUM AT 50°C AND 51°C






FIGURE 30. - TIME-WEIGHT HISTORIES FOR RTV-601 DURING EXPOSURE TO VACUUM AT 50°C AND 54°C




FIGURE 31. - TIME-WEIGHT HISTORIES FOR RTV-601 DURING EXPOSURE TO VACUUM AT 94°C, 100°C, 105°C, 106°C, AND 119°C




FIGURE 32. - TIME-WEIGHT HISTORIES FOR DCR-7521 DURING EXPOSURE TO VACUUM AT 53°C




FIGURE 33. - TIME-WEIGHT HISTORIES FOR DCR-7521 DURING EXPOSURE TO VACUUM AT 100°C AND 114°C




FIGURE 34. - TIME-WEIGHT HISTORIES FOR EC 2273 DURING EXPOSURE TO VACUUM AT 49°C, 50°C, 52°C, AND 54°C




FIGURE 35. - TIME-WEIGHT HISTORIES FOR EC 2273 DURING EXPOSURE TO VACUUM  
AT 98°C AND 104°C




FIGURE 36. - TIME-WEIGHT HISTORIES FOR DUROCK D-133 DURING EXPOSURE TO VACUUM AT 50°C AND 57°C




FIGURE 37. - TIME-WEIGHT HISTORIES FOR DUROCK D-133 DURING EXPOSURE TO VACUUM AT 100°C AND 114°C






FIGURE 38. - TIME-WEIGHT HISTORIES FOR FM-47 DURING EXPOSURE TO VACUUM AT 50°C, 51°C, AND 55°C




FIGURE 39. - TIME-WEIGHT HISTORIES FOR FM-47 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 40. - TIME-WEIGHT HISTORIES FOR PARAPLEX P-43 DURING EXPOSURE TO VACUUM  
AT 50°C AND 58°C




FIGURE 41. - TIME-WEIGHT HISTORIES FOR PARAPLEX P-43 DURING EXPOSURE TO VACUUM AT 99°C AND 105°C




FIGURE 42. - TIME-WEIGHT HISTORIES FOR CTL-91-LD DURING EXPOSURE TO VACUUM AT 50°C AND 54°C




FIGURE 43. - TIME-WEIGHT HISTORIES FOR CTL-91-LD DURING EXPOSURE TO VACUUM  
AT 100°C, 104°C, AND 105°C




FIGURE 44. - TIME-WEIGHT HISTORIES FOR EPON 828 DURING EXPOSURE TO VACUUM AT 48°C, 50°C, AND 55°C




FIGURE 45. - TIME-WEIGHT HISTORIES FOR EPON 828 DURING EXPOSURE TO VACUUM AT 100°C AND 101°C






FIGURE 46. - TIME-WEIGHT HISTORIES FOR DC-2104 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 47. - TIME-WEIGHT HISTORIES FOR DC-2104 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 48. - TIME-WEIGHT HISTORIES FOR DC-2106 DURING EXPOSURE TO VACUUM AT 41°C, 47°C, AND 50°C





FIGURE 49. - TIME-WEIGHT HISTORIES FOR DC-2106 DURING EXPOSURE TO VACUUM  
AT 100°C, 103°C, 105°C, AND 150°C



### CONTINUOUS TIME-HOURS; SCREENING TIME-DAYS

FIGURE 50. - TIME-WEIGHT HISTORIES FOR HRP HONEYCOMB DURING EXPOSURE TO VACUUM AT 50°C AND 51°C




FIGURE 51. - TIME-WEIGHT HISTORIES FOR HRP HONEYCOMB DURING EXPOSURE TO VACUUM AT 100°C AND 103°C




FIGURE 52. - TIME-WEIGHT HISTORIES FOR VITON B DURING EXPOSURE TO VACUUM  
AT 48°C AND 50°C




FIGURE 53. - TIME-WEIGHT HISTORIES FOR VITON B DURING EXPOSURE TO VACUUM AT 100°C, 149°C, AND 198°C






FIGURE 54. - TIME-WEIGHT HISTORIES FOR PRP 73770 DURING EXPOSURE TO VACUUM  
AT 47°C AND 50°C




FIGURE 55. - TIME-WEIGHT HISTORIES FOR PRP 73770 DURING EXPOSURE TO VACUUM  
AT 99°C, 100°C, AND 101°C




FIGURE 56. - TIME-WEIGHT HISTORIES FOR PRP 8187 DURING EXPOSURE TO VACUUM  
AT 46°C AND 50°C




FIGURE 57. - TIME-WEIGHT HISTORIES FOR PRP 8187 DURING EXPOSURE TO VACUUM AT 100°C AND 101°C




FIGURE 58. - TIME-WEIGHT HISTORIES FOR URETHANE DS-620 DURING EXPOSURE TO VACUUM AT 50°C AND 56°C




FIGURE 59. - TIME-WEIGHT HISTORIES FOR URETHANE DS-620 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 60. - TIME-WEIGHT HISTORIES FOR ECCOFOAM Q DURING EXPOSURE TO VACUUM  
AT 50°C and 51°C




FIGURE 61. - TIME-WEIGHT HISTORIES FOR ECCOFOAM Q DURING EXPOSURE TO VACUUM AT 99°C AND 100°C






FIGURE 62. - TIME-WEIGHT HISTORIES FOR REFRASIL B-100 DURING EXPOSURE TO VACUUM AT 50°C AND 51°C




FIGURE 63. - TIME-WEIGHT HISTORIES FOR REFRASIL B-100 DURING EXPOSURE TO VACUUM AT 100°C AND 101°C




FIGURE 64. - TIME-WEIGHT HISTORIES FOR CPR-20 DURING EXPOSURE TO VACUUM AT 43°C, 48°C, AND 50°C




FIGURE 65. - TIME-WEIGHT HISTORIES FOR CPR-20 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 66. - TIME-WEIGHT HISTORIES FOR CPR-1021 DURING EXPOSURE TO VACUUM  
AT 50°C AND 54°C




FIGURE 67. - TIME-WEIGHT HISTORIES FOR CPR-1021 DURING EXPOSURE TO VACUUM AT 99°C AND 100°C




FIGURE 68. - TIME-WEIGHT HISTORIES FOR DUROID 5813 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 69. - TIME-WEIGHT HISTORIES FOR DUROID 5813 DURING EXPOSURE TO VACUUM AT 100°C AND 101°C






FIGURE 70. - TIME-WEIGHT HISTORIES FOR EPON VIII DURING EXPOSURE TO VACUUM AT 50°C AND 51°C




FIGURE 71. - TIME-WEIGHT HISTORIES FOR EPON VIII DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 72. - TIME-WEIGHT HISTORIES FOR APCO 1252 DURING EXPOSURE TO VACUUM  
AT 50°C, 52°C, AND 54°C




FIGURE 73. - TIME-WEIGHT HISTORIES FOR APCO 1252 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 74. - TIME-WEIGHT HISTORIES FOR SHELL 929 DURING EXPOSURE TO VACUUM AT 50°C AND 52°C




FIGURE 75. - TIME-WEIGHT HISTORIES FOR SHELL 929 DURING EXPOSURE TO VACUUM AT 100°C AND 105°C




FIGURE 76. - TIME-WEIGHT HISTORIES FOR SHELL 934 DURING EXPOSURE TO VACUUM AT 43°C AND 50°C




FIGURE 77. - TIME-WEIGHT HISTORIES FOR SHELL 934 DURING EXPOSURE TO VACUUM  
AT 78°C AND 100°C






FIGURE 78. - TIME-WEIGHT HISTORIES FOR HT-424 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 79. - TIME-WEIGHT HISTORIES FOR HT-424 DURING EXPOSURE TO VACUUM AT 100°C





FIGURE 80. - TIME-WEIGHT HISTORIES FOR NARMCO A DURING EXPOSURE TO VACUUM AT 50°C






FIGURE 82. - TIME-WEIGHT HISTORIES FOR NARMCO C DURING EXPOSURE TO VACUUM  
AT 50°C, 54°C, AND 57°C




FIGURE 83. - TIME-WEIGHT HISTORIES FOR NARMCO C DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 84. - TIME-WEIGHT HISTORIES FOR AEROBOND 430 DURING EXPOSURE TO VACUUM AT 50°C AND 57°C




FIGURE 85. - TIME-WEIGHT HISTORIES FOR AEROBOND 430 DURING EXPOSURE TO VACUUM AT 100°C






FIGURE 86. - TIME-WEIGHT HISTORIES FOR FM-1000 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 87. - TIME-WEIGHT HISTORIES FOR FM-1000 DURING EXPOSURE TO VACUUM AT 100°C AND 101°C




FIGURE 88. - TIME-WEIGHT HISTORIES FOR NARMCO 302A DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 89. - TIME-WEIGHT HISTORIES FOR NARMCO 302A DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 90. - TIME-WEIGHT HISTORIES FOR AF-6 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 91. - TIME-WEIGHT HISTORIES FOR AF-6 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 92. - TIME-WEIGHT HISTORIES FOR AF-40 DURING EXPOSURE TO VACUUM AT 48°C AND 50°C




FIGURE 93. - TIME-WEIGHT HISTORIES FOR AF-40 DURING EXPOSURE TO VACUUM AT 100°C AND 102°C






FIGURE 94. - TIME-WEIGHT HISTORIES FOR NARMCO 4021 DURING EXPOSURE TO VACUUM AT 49°C AND 50°C




FIGURE 95. - TIME-WEIGHT HISTORIES FOR NARMCO 4021 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 96. - TIME-WEIGHT HISTORIES FOR NARMCO 408 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 97. - TIME-WEIGHT HISTORIES FOR NARMCO 408 DURING EXPOSURE TO VACUUM AT 99°C AND 100°C




FIGURE 98. - TIME-WEIGHT HISTORIES FOR SELECTRON 5003 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 99. - TIME-WEIGHT HISTORIES FOR SELECTION 5003 DURING EXPOSURE TO VACUUM AT 95°C AND 100°C




FIGURE 100. - TIME-WEIGHT HISTORIES FOR KYNAR DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 101. - TIME-WEIGHT HISTORIES FOR KYNAR DURING EXPOSURE TO VACUUM AT 100°C






FIGURE 102. - TIME-WEIGHT HISTORIES FOR MB 302A DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 103. - TIME-WEIGHT HISTORIES FOR MB 302A DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 104. - TIME-WEIGHT HISTORIES FOR MB 406 DURING EXPOSURE TO VACUUM AT 50°C AND 54°C




FIGURE 105. - TIME-WEIGHT HISTORIES FOR MB 406 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 106. - TIME-WEIGHT HISTORIES FOR MB 4021 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 107. - TIME-WEIGHT HISTORIES FOR MB 4021 DURING EXPOSURE TO VACUUM AT 100°C AND 102°C




FIGURE 108. - TIME-WEIGHT HISTORIES FOR SCOTCHCAST 212 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 109. - TIME-WEIGHT HISTORIES FOR SCOTCHCAST 212 DURING EXPOSURE TO VACUUM AT 100°C AND 103°C






FIGURE 110. - TIME-WEIGHT HISTORIES FOR EC 1949 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 111. - TIME-WEIGHT HISTORIES FOR EC 1949 DURING EXPOSURE TO VACUUM AT 98°C AND 100°C




FIGURE 112. - TIME-WEIGHT HISTORIES FOR EC 1663 DURING EXPOSURE TO VACUUM AT 50°C AND 51°C




FIGURE 113. - TIME-WEIGHT HISTORIES FOR EC 1663 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 114. - TIME-WEIGHT HISTORIES FOR PR-1538 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 115. - TIME-WEIGHT HISTORIES FOR PR-1538 DURING EXPOSURE TO VACUUM AT 100°C AND 101°C




FIGURE 116. - TIME-WEIGHT HISTORIES FOR MOLYKOTE X-15 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 117. - TIME-WEIGHT HISTORIES FOR MOLYKOTE X-15 DURING EXPOSURE TO VACUUM AT 100°C






FIGURE 118. - TIME-WEIGHT HISTORIES FOR ELECTROFILM 66-C DURING EXPOSURE TO VACUUM AT 44°C, 49°C, AND 50°C




FIGURE 119. - TIME-WEIGHT HISTORIES FOR ELECTROFILM 66-C DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 120. - TIME-WEIGHT HISTORIES FOR MLF-5 DURING EXPOSURE TO VACUUM AT 50°C




FIGURE 121. - TIME-WEIGHT HISTORIES FOR MLF-5 DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 122. - TIME-WEIGHT HISTORIES FOR ETR-H DURING EXPOSURE TO VACUUM  
AT 50°C AND 54°C




FIGURE 123. - TIME-WEIGHT HISTORIES FOR ETR-H DURING EXPOSURE TO VACUUM AT 100°C




FIGURE 124. - TIME-WEIGHT HISTORIES FOR EPOXY COATING ON ALUMINUM DURING EXPOSURE TO VACUUM AT 49°C AND 50°C




FIGURE 125. - TIME-WEIGHT HISTORIES FOR EPOXY COATING ON ALUMINUM DURING EXPOSURE TO VACUUM AT 98°C AND 100°C






FIGURE 126. - TIME-WEIGHT HISTORIES FOR EPOXY COATING PEELED OFF GLASS DURING EXPOSURE TO VACUUM AT 47°C AND 50°C




FIGURE 127. - TIME-WEIGHT HISTORIES FOR EPOXY COATING PEELED OFF GLASS DURING EXPOSURE TO VACUUM AT 100°C AND 103°C




FIGURE 128. - TIME-WEIGHT HISTORIES FOR MERLON DURING EXPOSURE TO VACUUM  
AT 54°C AND 55°C





FIGURE 129. - TIME-WEIGHT HISTORIES FOR MERLON DURING EXPOSURE TO VACUUM AT 137°C AND 140°C



### INTERMITTANT WEIGHING TEST RESULTS AT 24 HRS, WEIGHT LOSS, PERCENT

FIGURE 130. - COMPARISON OF RESULTS FROM CONTINUOUS WEIGHING TEST AND INTERMITTENT WEIGHING TEST

June 24, 1965

APPROVAL


NASA TM X-53286


VACUUM COMPATIBILITY OF ENGINEERING  
MATERIALS (SOLIDS) II


By J. G. Austin and J. B. Gayle

The information in this report has been reviewed for security classification. Review of any information concerning Department of Defense or Atomic Energy Commission programs has been made by the MSFC Security Classification Officer. This report, in its entirety, has been determined to be unclassified.

This document has also been reviewed and approved for technical accuracy.

*for*   
W. A. RIEHL  
Chief, Chemistry Branch

  
W. R. LUCAS  
Chief, Materials Division

*for*   
F. B. CLINE  
Acting Director, Propulsion and Vehicle Engineering Laboratory

## DISTRIBUTION

R-P&VE-DIR	Mr. Cline
R-P&VE-V	Mr. Aberg
R-P&VE-S	Mr. Kroll
R-P&VE-P	Mr. Paul
R-P&VE-PM	Mr. Langston
R-P&VE-M	Dr. Lucas (5)
R-P&VE-ME	Mr. Kingsbury (3)
R-P&VE-MN	Mr. Shannon
R-P&VE-MM	Mr. Cataldo
R-P&VE-MM	Mr. Franklin
R-P&VE-MC	Mr. Riehl (25)
R-P&VE-MC	Mr. Nunnelley
R-SA	Dr. Kuettner
R-ASTR-DIR	Dr. Haeussermann
R-ASTR-PE	Mr. Van Orden
R-ASTR-M	Mr. Lamb
R-RP-DIR	Dr. Stuhlinger
R-QUAL-DIR	Mr. Grau
R-QUAL-M	Mr. Henritze (3)
R-ASTR-RT	Mr. Kirby
R-AERO-S	Mr. Ballance
R-TEST-C	Mr. Connor
CC-P	Mr. Reece
MS-H	Mr. Akens
MS-I	Mr. Remer
MS-IPL	Miss Robertson (8)
R-P&VE-RT	Mr. Hofues
MS-T	Mr. Wiggins

Jet Propulsion Laboratory  
California Institute of Technology  
4800 Oak Grove Drive  
Pasadena, California 91103  
Attn: Dr. L. Jaffe/Mr. E. L. Leventhal/Dr. Tony Havlick

Douglas Aircraft Company, Incorporated  
3000 Ocean Park Boulevard  
Santa Monica, California 90405  
Attn: Mr. C. Hedges

DISTRIBUTION (Continued)

North American Aviation  
Space and Information Systems Division  
Downey, California 91341  
Attn: Messrs. B. Healy/J. O. Laws/D. Simkin/D. Drysol

Aeronutronic  
A Division of Ford Motor Company  
Ford Road  
P. O. Box 697  
Newport Beach, California 92660  
Attn: Mr. F. M. Black

General Electric Company  
Valley Forge Space Technology Center  
P. O. Box 8555  
Philadelphia, Pennsylvania 19101  
Attn: Mr. Carl P. Boebel, Materials Evaluation  
M&P Engineering, Room 4223-U

Minneapolis-Honeywell Regulator Company  
2600 Ridgeway Road  
Minneapolis, Minnesota 55424  
Attn: Mr. Luther L. Bolstad  
Materials Engineering - 636

Fluidyne Engineering Corporation  
5740 Wayzata Boulevard  
Godlen Valley  
Minneapolis, Minnesota 55416  
Attn: Mr. Y. E. Joarnt

Arthur D. Little, Incorporated  
1424 Fourth Street  
Santa Monica, California 90401  
Attn: Mr. I. Eric Randall

General Dynamics/Pomona  
Pomona, California 91766  
Attn: Mr. J. S. Roberts

Aerojet-General Corporation  
Azusa, California 91702  
Attn: Mr. V. G. Olcott



DISTRIBUTION (Concluded)

Bell Telephone Laboratories, Incorporated  
Murray Hill, New Jersey 07971  
Attn: Mr. John Simpson

Headquarters  
Mobile Air Material Area, USAF  
Brookley Air Force Base  
Mobile, Alabama 36615  
Attn: Mr. Robert Wilson, MOSPR

Mr. Bernard Achhammer, RRM  
National Aeronautics and Space Administration  
Washington, D. C. 20546

Dr. Henry Frankel  
National Aeronautics and Space Administration  
Goddard Space Flight Center  
Greenbelt, Maryland 20771

Mr. Charles A. Hermach  
National Aeronautics and Space Administration  
Ames Research Center  
Moffett Field, California 94035

Dr. George F. Pezdirtz  
National Aeronautics and Space Administration  
Langley Research Center  
Langley Station  
Hampton, Virginia 23365

Scientific and Technical Information Division (25)  
P. O. Box 5700  
Bethesda, Maryland 20014  
Attn: NASA Representative (S-AK/RKT)